




TANDEM MODULATING VALVE

Service Instructions

TABLE 1 (Specifications)

Model Number	Valve Assembly Number	Repair Kit Number	Brake Pressure Setting	
			bar	(PSI)
06-466-561	20-200-194	06-400-510	60 ± 3.4	(870 ± 50)
4071013150	4071013152	06-400-510	60 ± 3.4	(870 ± 50)

NOTE: If your model number is not listed, contact ZF Off-Highway Solutions Inc. for information.



This publication is not subject to any update service. Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. ZF Off-Highway Solutions Minnesota Inc. reserves the right to revise the information presented or to discontinue the production of parts described at any time.



ZF Off-Highway Solutions Minnesota Inc.
 1911 Lee Boulevard / North Mankato, MN U.S.A. 56003
 Tel: +1 507 625 6426 Fax: +1 507 625 3212

DISASSEMBLY

(Refer to Figures 1 and 2)

NOTE

Housings (6 & 12) and spools (7 & 11) are manufactured as matched sets. These sets, housing and spool, must not be intermixed with other parts.

1. Remove boot (23) from retainer (21) and piston (18).
2. Remove retainer (21), piston (18), springs (17, 16, & 15), shim(s) (14), and retainer assembly (13) from housing (12).
NOTE: Be aware of the number of shim(s) being removed from housing.
3. Carefully remove cup (22), quad ring (19), and o-ring (20) from retainer (21). Note direction and order of cup and quad ring. **NOTE: Be careful not to scratch or mar retainer bore.**
4. Remove end plug (1) and spring (3) from housing (6). Remove o-ring (2) from end plug (1).
5. Separate housings (6 & 12) by removing cap screws (4) and washers (5). Remove o-ring (8), spring (9), and retainer (10) from housings (6 & 12).
6. Carefully remove spools (7 & 11) from housings (6 & 12).
NOTE: Be careful not to damage spools or housing bores.

CAUTION

Do not intermix spools and housings. Spool (7) and housing (6) are a matched set as are spool (11) and housing (12).

ASSEMBLY

(Refer to Figures 1 and 2)

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM.

1. Clean all parts thoroughly and allow to dry before assembling.
2. Lubricate spool (11) with clean system fluid and carefully slide into bottom side of housing (12) bore. Note direction of spool (11). **NOTE: Spool must slide freely into bore. If either part is damaged, a new valve assembly may be required.**
3. Install new o-ring (8), spring (9), and retainer (10) on housings (6 & 12).
4. Reassemble housings (6 & 12) using cap screws (4) and washers (5). Use Loctite 242 on cap screws and torque 29.8-33.9 N·m (22-25 lb-ft). **NOTE: Make sure housings line up correctly and that o-ring (8), spring (9), and retainer (10) remain in their pockets during assembly.**
5. Lubricate spool (7) with clean system fluid and carefully slide into housing (6) bore. Note direction of spool (7).
NOTE: Spool must slide freely into bore. If either part is damaged, a new valve assembly may be required.
6. Install new o-ring (2) on end plug (1).
7. Install spring (3) and end plug (1) into housing (6). Torque end plug (1) 47.5-61.0 N·m (35-45 lb-ft).
8. Carefully install new cup (22), new quad ring (19), and new o-ring (20) on retainer (21). Note direction and order of cup and quad ring. **NOTE: Be careful not to scratch or mar retainer bore.**




FIGURE 2

9. Assemble springs (17, 16, & 15), shim(s) (14), and retainer assembly (13) in piston (18).
10. Carefully install retainer (21) over piston (18) and install retainer (21) assembly into housing (12). Torque retainer 81.4-101.7 N·m (60-75 lb-ft).
11. Install new boot (23) on retainer (21) and piston (18).

NOTE

After service, the valve must develop the pressure indicated in the specifications, TABLE 1. Shim(s) (14) are used to obtain the correct pressure setting. Contact ZF Off-Highway Solutions Minnesota Inc. if brake pressure setting is not able to be obtained.