


Single MODULATING VALVE with pilot apply



Service Instructions

TABLE 1 (Specifications)

Complete Unit Model Number	Repair Kit Number	Brake Pressure Setting	
		bar	(PSI)
06-466-300	06-400-203	56.9	1.7 (825 25)



⚠ WARNING

Installation and test note: Piston (19) must be retained mechanically. This will prevent it from blowing out at high velocity if an incorrect connection occurs from power source to tank ports. **Be sure the tank ports are connected directly to tank.** Failure to do this could result in serious injury or death.

This publication is not subject to any update service. Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. ZF Off-Highway Solutions Minnesota Inc. reserves the right to revise the information presented or to discontinue the production of parts described at any time.



ZF Off-Highway Solutions Minnesota Inc.

1911 Lee Boulevard / North Mankato, MN U.S.A. 56003

Tel: +1 507 625 6426 **Fax:** +1 507 625 3212

BLEEDING

Brakelines should be bled very carefully as soon as the valve is installed in the machine. Air in the system will not allow the brakes to release properly and may severely damage them.

1. Start engine and allow accumulator to reach full charge. Shut down engine, then slowly apply and release brakes, waiting one minute between applications until brakes will not apply. Repeat this step three times.
2. Operate engine to maintain accumulator pressure within

working limits throughout the bleeding procedure.

3. Open bleeder screw at wheel closest to brake valve and apply brakes cautiously until all air is bled out of line. Then close bleeder screw. Repeat this step at each wheel, moving to the next farthest wheel from the brake valve each time, as follows:
 - a. Left front
 - b. Right front
 - c. Right rear
 - d. Left rear

4. Release brake pressure for at least one (1) minute.
5. Apply brakes, holding pedal down 10 seconds; then release pressure for one (1) minute. Repeat this step two more times.
6. Repeat step 3.
7. Check for system leaks and be sure of proper brake operation.

SERVICE CHECKS FOR 466 SERIES SINGLE PEDAL VALVES

BRAKES SLOW TO APPLY

1. No or improper gas charge in accumulator
 1. **Check gas charge**
 2. Brakes not properly adjusted
 2. **Adjust brakes**
 3. Inoperative brakes
 3. **Check brakes**
 4. Hydraulic lines or fittings leaking
 4. **Check for leaks and repair**
 5. Inoperative automatic adjuster (Goodrich Hi-torque Brakes only)
 5. **Check adjuster operation**
 6. Damaged hydraulic brake lines
 6. **Check lines for dents that restrict flow of oil**

BRAKES WILL NOT RELEASE

1. Pedal angle out of adjustment
 1. **Check for proper pedal angle**
 2. Inoperative brakes
 2. **Check brakes**
 3. Inoperative automatic adjusters
 3. **Check operation of adjusters**
 4. Inoperative brake valve
 4. **Replace brake valve**

INSUFFICIENT BRAKES

1. No oil or low oil level in tank
 1. **Check oil level in tank**
 2. Brakes not properly adjusted
 2. **Check brake adjustment**
 3. Oil or grease on brake lining
 3. **Clean or install new linings**

SERVICE DIAGNOSIS

All item numbers discussed here refer to Figures 1 and 2.

BRAKES WILL NOT RELEASE COMPLETELY

1. Piston (17) binding
2. Pedal angle out of adjustment
3. Spring (3) broken

BRAKES WILL NOT RELEASE

1. Binding spool (4)
2. Piston (17) binding

4. Brake line damaged
4. **Check lines and replace**
5. Inoperative automatic adjusters
5. **Check operation of adjusters**
6. No or improper gas charge in accumulator
6. **Check gas charge**
7. Inoperative brakes
7. **Check brakes**
8. Brake valve inoperative
8. **Replace valve**

EXCESSIVE BRAKING

1. Inoperative brakes
 1. **Check brakes**
 2. Inoperative brake valve
 2. **Replace brake valve**

BRAKES WILL NOT RELEASE COMPLETELY

1. Brakes not properly adjusted
 1. **Adjust brakes**
 2. Inoperative brakes
 2. **Check brakes**
 3. Pedal angle out of adjustment
 3. **Adjust pedal angle**
 4. Inoperative wheel cylinders
 4. **Replace wheel cylinders**
 5. Inoperative automatic adjuster
 5. **Check operation of adjusters**
 6. Air in brakes (when automatic adjusters used Goodrich Hi-torque Brakes only)
 6. **Bleed brakes**

NO BRAKES

1. Piston (17) binding
2. Broken spring (13)

EXCESSIVE BRAKING

1. Too many shims (12) installed in valve

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE APPLIED

1. Damaged spool (4)

7. Inoperative brake valve
7. **Replace brake valve**
8. Back pressure on return line too high
8. **Remove restriction**

NO BRAKES

1. No oil in hydraulic system
 1. **Check oil level in tank**
 2. Broken or damaged brake line
 2. **Check lines for breaks or damaged condition**
 3. Brakes not properly adjusted
 3. **Adjust brakes**
 4. Inoperative system relief valve
 4. **Check pressure in pressure line to valve**
 5. Worn pump
 5. **Check pressure in pressure line to valve**
 6. Inoperative automatic adjuster
 6. **Check brake line pressure**
 7. Inoperative or worn brakes
 7. **Check brakes**
 8. Inoperative brake valve
 8. **Replace brake valve**

PEDAL KICKBACK WHEN BRAKES ARE APPLIED

1. Air in brakes
 1. **Bleed brakes**

EXCESSIVE ACCUMULATOR LEAKAGE WHEN BRAKES ARE NOT BEING USED

1. Damaged spool (4)
2. Spring (3) broken

INSUFFICIENT BRAKES

1. Broken pressure regulating spring (13)
2. Pedal travel is inhibited